
OUSEI®

User's Manual

Model:OU981



Ver.3.0

Dear Customer,

Thank you for choosing our product.

This product has been manufactured with a strong commitment to quality and attention to detail, providing a comfortable and efficient typing experience.

To ensure you make full use of all product features,
please read this user manual carefully before use and keep it for future reference.

Image Disclaimer

The illustrations and photographs in this manual and on the product packaging are for reference only.
The actual product may vary slightly from those shown.

Product design and specifications may be changed without prior notice for improvement purposes.
The actual product shall prevail.

Safety Information and Disclaimer

To ensure safe operation and maximize the use of the product, please observe the following precautions:

- Operate the keys gently. Do not use sharp objects on the keys or scratch the product surface.
- When connecting or disconnecting the USB cable, hold the connector firmly. Do not pull on the cable itself.
- Disconnect the keyboard from your computer before cleaning. Use a soft, dry cloth for cleaning. For stubborn stains, use a cloth lightly dampened with a mild detergent. Do not use harsh chemicals or wash the product directly with water.

The company shall not be liable for product damage, malfunction, or any indirect loss caused by:

- Failure to follow the instructions in this manual;
- Dropping the product, liquid intrusion, improper disassembly, or force majeure events such as earthquakes, fire, or flooding;
- Repairs or modifications performed without authorization from the company.

After-Sales Service and Support

We are committed to providing comprehensive after-sales support to our customers.

Warranty Policy


This product is covered by a limited one-year warranty from the date of purchase.
During the warranty period, if a manufacturing defect occurs under normal use,
you may be eligible for free repair or replacement service upon presentation of valid proof of purchase.

Contact Us

If you experience any issues while using the product or require after-sales support, please contact us at:

Email:hdr7es@163.com

Function Overview



①Right knob
The volume switch is made of metal.
Turning the metal knob can adjust the volume.

②Mode switch
BT: Bluetooth mode I OFF: off I USB: Wired mode

How to Connect via Bluetooth
1) Switch to the "BT" position
2) Press FN, don't release, then press Q, keep both buttons pressed for 3 seconds. The first indicator light of the keyboard will flash.If FN + Q doesn't work, please try using FN + W or FN + E instead
3) Turn on the Bluetooth function of your device, search for "ML-981" and connect. The indicator will remain solid blue after successful connection.


How to connect a device with wired mode
1) Switch to the "USB" position
2) Connect the keyboard and device with a USB-C cable in the packing.

③System switch
Window /Android System
Mac / ios System


④Type-C port Port
When the fourth indicator light turns red, it needs to be charged with the USB-C charging cable. It normally takes around 6 hours to fully charge.

⑤Left turn button
Turn the metal knob to adjust the brightness of the light.

⑥Lever
The pull rod of the electroplating process can switch thebacklight mode by pulling the switch.



Indicator description



①MODE INDICATOR
WIRED MODE(The indicator is red)
Turn the switch to USB position, the typewriter useUSB-C cable connect with PC/Laptop, it is wired mode.
Tips: In wired mode, Please use the included cable to connect the computer and keyboard.

BLUETOOTH MODE(The indicator is blue)
Turn the switch to BT position, press FN+Q / W / E keys and hold for 3 seconds, the first indicator keep blue flashing at this time, then open the bluetooth switch in the device tofinish pairing.
OFF(Turn off the power)

②WIN LOCK INDICATOR
Press FN+WIN key is the windows lock key switch.
The light is blue when Win Lock Function is open, and Win key have no function at the same time.
The light is off when lock key is closed and the Win key function will be restored.

③CAPITALS LOCK INDICATOR(Aa)

Pressing the CAPS key is the caps lock switch. The indicator light is blue when the caps lock funtion is turned on, and the light is off when press it again ,and the CAPS lock function is turned off.

④CHARGING INDICATOR

When the voltage is lower than 3.4(need to be charged), he indicator light is red and fashing;the red light fixed when charging. It lights up in blue when it is full.When using individual mobile phone chargers to charge the keyboard, the indicatorlight will not light up.



FN combination Keys Manual

Window/Android

FN+F1	My Computer
FN+F2	Search
FN+F3	Calculator
FN+F4	Multimedia
FN+F5	Last Song
FN+F6	Next Song
FN+F7	Pause
FN+F8	Stop
FN+F9	Mute
FN+F10	Volume +
FN+F11	Volume -
FN+F12	Keyboard Lock
FN+Win	Win Lock

Mac /ios

F1	Screen Brightness-
F2	Screen Brightness+
F3	Call out all programs (Mac work IOS None)
F4	Launchpad (Mac work Ios None)
F5	Keyboard Brightness-
F6	Keyboard Brightness+
F7	Last Song
F8	Play / Pause
F9	Next Song
F10	Mute
F11	Volume -
F12	Volume +
Prtsc	Screenshot
Pause	Start-up Siri

Backlight combination keys manual

FN+↑ FN+↓	Adjust the lightness
FN+← FN+→	Adjust the speed of flashing
FN+Del	Backlight ON/OFF
FN+Home	Switch Lighting Mode
FN+Esc	Press 3 seconds to restore the original design

Multi-device Bluetooth mode combination keys

①The Bluetooth of the three devices is paired and connected to the corresponding FN+Q/FN+W/ FN+E.
②How to switch among 3 devices:
Press FN+Q/W/E= Device 1 or Device 2 or Device3

Sleep patterns

In the Bluetooth mode, it will enter sleep after 5 minutes without pressing any key. It needs 1 second to rework

Switch Specifications

Blue Switch
Durability: Over 50 Million Keystrokes
Operating Force: 45±50gf
Actuation Point: 2.2±0.5mm
Switch Type: Tactile
Total Travel: 4.0+0/-0.6mm

Red Switch
Durability: Over 50 Million Keystrokes
Operating Force: 45±50gf
Actuation Point: 2.2±0.5mm
Switch Type: Linear
Total Travel: 4.0+0/-0.5mm

SPECIFICATIONS DATA

Number of keys: 83(Mechanical Blue Switch)
Number of Multimedia Keys: 12
Materials: ABS & Metal
Battery: 2,000mAh
Charging Time: Around 6 hrs
Interface: USB-C
Mode: Bluetooth & Wired
Cable length: 1.6meters

BT Device Name: ML-981
Switch lifespan: >50millions
Keyboard function: All keys anti-ghosting
Bluetooth Version: 5.0
Report rate:125Hz
Dimensions: 32.5 x 17 x 4 cm
Dimensions: 12.8 x 6.7 x 1.6 inch
Net Weight: 720g Net Weight: 1.6lb

WHAT'S IN THE BOX

Typewriter BT*1
Metal Switch Puller*1
Spare Switch *2
Micro USB-C Cable*1
User Manual*1

Customer Support

How to Connect Bluetooth


Website

Brand:OUSEI
Brand owner:Shenzhen Liqian Technology Co., Ltd.
Customer Support:hdr7es@163.com
Website:www ouseitech.com
Product Standard:GB/T 14081-2010
Copyright© Liqian Technology Co., Ltd. All Rights Reserved.

OUSEI®

取扱説明書

品番：OU981



Ver.3.0

お客様へ

このたびは当社製品をお選びいただき、誠にありがとうございます。

本製品は、快適で効率的なタイピング体験をお楽しみいただけるよう、品質と細部へのこだわりをもって設計・製造されています。

製品の機能を十分にご活用いただくため、ご使用前に本取扱説明書をよくお読みいただき、必要な時に参照できるよう大切に保管してください。

【商標について】

本書および製品パッケージに掲載されている図や写真はイメージです。実際の製品とは一部異なる場合があります。

製品のデザインおよび仕様は、品質向上のため予告なく変更される場合がありますあらかじめご了承ください。最終的な仕様は実際の製品を優先します。

【安全上のご注意および免責事項】

安全にご使用いただき、製品寿命を維持するため、以下の事項を必ず守りください。

・キーは優しく操作してください。脱利な物でキーを押したり、表面を傷つけたりしないでください。

・USBケーブルを接続または取り外す際は、ケーブルを引っ張らず、必ずコネクタ部分を持って操作してください。

・連続を行う前には、必ずキーボードをコンピューターから取り外してください。柔らかく乾いた布で拭いてください。汚れがひどい場合は、中性洗剤を少量含ませた布で軽く拭き取ってください。強力な化学薬品の使用やにおける直接洗浄は行わないでください。

以下の事由により生じた製品の故障、損傷、または間接的な損害について、当社は責任を負いかねます。

・本書の指示に従わない使用、保管、または誤メンテナンスによる場合

・落下、液体の浸入、不適切な分解、地震、火災、水害などの不可抗力による損害

・当社が認可していない修理または改造による損害

【アフターサービスおよびサポート】


当社はお客様に安心してご利用いただけるよう、充実したアフターサービスをご提供しております。

保証内容：
本製品には、ご購入日から1年間の限定保証が付帯しています。保証期間内に正常な使用状態で品質上の不具合が発生した場合、有効な購入証明書をご提示いただくことで、無償修理または交換サービスをご利用いただけます。

お問い合わせ：
製品の使用方法や不具合に関するご相談、アフターサービスをご希望の場合は、下記までお気軽にお問い合わせください。

メールアドレス:umkelqvd58x9ag@yahoo.co.jp

機能説明



① 右つまみ

② モード切り替えスイッチ

③ OS切り替えスイッチ

④ Type-Cポート

①右つまみ
抜きことでボリュームを調整できます。

②モード切り替えスイッチ
BT：BTモード/OFF：電源OFF/USB：有線モード

BTモード接続方法
1) スイッチをBTにします



2) FN+Q/W/Eの約三秒長押しでペアリングモードに入ります。ランプ①とQ/W/Eキーが点滅します。
3) デバイスのBTをオンにしてML-981を検索して接続します。BTモードの場合は、ランプ①は青く等時点灯となります。

有線モード接続方法
1) スイッチをUSBにします。



2) 同梱のケーブルでデバイスと接続します。


③OS切り替えスイッチ



④Type-Cポート
ランプ④が赤くなったら、Type-Cケーブルで充電するお必要があると意味します。充電時間はおおよそ4時間かかります。

⑤左つまみ
抜きことで輝度を調整できます。

⑥レバー
引っ張ることでバックライトモードを変更できます。



ランプ表示




① モード表示
有線モード：ランプが赤くなります。
スイッチをUSBにしてケーブルをパソコンに接続したら、有線接続が成功となります。同梱のケーブルで接続する場合のみ、ランプ①は点灯します。
BTモード：ランプが青くなります。

スイッチをBTにしてFN＋Q/W/Eで約3秒押して、ランプ①が青く点滅、接続成功となったら、使用可能となります。スイッチをoffにしたら、電源をオンにすることを意味します。

② Winロック表示
FN+WinでWindowsキーをロックします。ロックされた場合はランプ②は青くなり、Winキーが無効化されるようになります。
ロック解除された場合はWinキーは動作可能で、ランプ②は消灯します。

③ キャプスロック表示
CAPSキーでCaps lock をオン/オフすることが可能です。
オンの場合はランプ③が青くなります。オフの場合は消灯します。

④ 充電表示
バッテリー残量が3.4Vより下となったら、ランプ④が赤くなって点滅し、充電が必要という意味です。充電の際にランプ④が青くなって常時点充電が完了したら、消灯となります。同梱のケーブルで接続する場合のみ、ランプ①は点灯します。



FN ショートカットキー

Window/Android

FN+F1	マイコンピュータ
FN+F2	検査
FN+F3	電卓
FN+F4	音楽
FN+F5	前の曲
FN+F6	次の曲
FN+F7	再生
FN+F8	停止
FN+F9	消音モード
FN+F10	ボリュームを下げる
FN+F11	ボリュームを上げる
FN+F12	キーボードロック
FN+Win	Winロック

Mac/ios

F1	輝度を下げる
F2	輝度を上げる
F3	マルチタスク制御ウィンドウ
F4	コンソール
F5	バックライトの輝度を下げる
F6	バックライトの輝度を上げる
F7	前の曲
F8	再生/停止
F9	次の曲
F10	静音
F11	ボリュームを下げる
F12	ボリュームを上げる
Prtsc	スクリーンショット
Pause	SIRIを起動する

バックライトショートカットキー

FN+↑ FN+↓	バックライト輝度調整
FN+← FN+→	バックライト速度調整
FN+Del	バックライトON/OFF
FN+Home	ライトモードを切り替える
FN+Esc	3秒長押しすると初期設定に戻ります

BTデバイス切り替えショートカットキー

①FN+Q/W/Eでデバイス最大三台と接続可能。
②FN+Q/W/Eで三つの接続済みのデバイスをそれぞれ切り替え可能。

スリープモード

BTモードの場合、5分以上となる任意のキーを押すとスリープモードから復帰します。

キースイッチ仕様

青軸	赤軸
耐久性＝50万回	耐久性＝50万回以上
動作力＝45±50gf	動作力＝45±50gf
作動点＝2.2±0.5mm	作動点＝2.2±0.5mm
操作タイプ＝タクタイル	操作タイプ＝リニア
総ストローク＝4.0+0/-0.6mm	総ストローク＝4.0+0/-0.5mm

仕様パラメータ

キーの数：83キー
マルチメディアキーの数：12キー
素材：ABSと金属
バッテリー：2000mAh
充電時間：約6時間
充電ポート：Type-C
接続モード：有線モードとBTモード
Bluetoothバージョン：5.0

BT名称：981
スイッチ寿命：＞50万回
キーの機能：全キー衝突防止
レポートレート：125Hz
ケーブルの長さ：1.6M
寸法：32.5 x 17 x 4 cm
本体重量：約713g

梱包リスト

キーボード*1
金属キープラー*1
予備スイッチ*2
Type-Cケーブル*1
説明書*1



カスタマーサポート



Bluetoothの接続方法




公式サイト

ブランド:OUSEI
販売元:リッセン株式会社
カスタマーサポート:umkelqvd58x9ag@yahoo.co.jp
公式サイト:www. liqian.co.jp
適用規格:GB/T 14081-2010
著作権© リッセン株式会社

OUSEI®

使用说明书

型号:OU981



Ver.3.0

尊敬的用户：

感谢您选择我们的产品。

本产品秉承对品质与细节的严格要求而设计制造，旨在为您带来舒适，高效的打字体验。

为了充分发挥产品功能，请在使用前仔细阅读本说明书，并妥善保存以备查阅。

【关于图片】

本说明书及产品包装上的图片和示意图仅供参考，实际产品可能与图片存在细微差异。

产品设计及规格可能因产品升级而在不另行通知的情况下进行调整，最终请以实物为准。

【安全注意事项及免责声明】

为了确保安全使用并延长产品使用寿命，请遵守以下事项：

- 请轻柔操作按键，避免使用尖锐物体敲击或划伤产品表面。
- 插拔USB连接线时，请握住连接器部分操作，切勿直接拉拽线材。
- 清洁前请先断开键盘与电脑的连接，建议使用柔软干布擦拭；如需深度清洁，可使用少量中性清洁剂轻轻擦拭。请勿使用强腐蚀性化学品或直接用水清洗。

对于因以下原因导致的产品故障、损坏或其他间接损失，本公司不承担责任：

- 未按照本说明书要求进行使用、维护或保管；
- 跌落、液体进入、撞自拆解、以及地震、火灾、水灾等不可抗力因素造成的损坏；
- 未经本公司授权的维修或改装行为。

【售后服务与支持】

我们致力于为您提供完善的售后服务。

保修政策：
本产品自购买之日起享有1年有限保修服务，在保修期内，如在正常使用条件下出现产品质量问题，凭有效购买凭证可享受免费维修或更换服务。

联系我们：
如您在使用过程中遇到任何问题，或需要售后服务支持，请通过以下方式联系我们。

电子邮箱：
fangjufang@li-qian.com

功能说明



① 右旋钮
旋转旋钮可调节音量大小。

② 模式开关
BT:蓝牙模式/OFF:关机/USB:有线模式

使用蓝牙模式连接设备
1)将模式开关切换到"BT"位置

2)按住F8和Q/W/E键并保持3秒，进入蓝牙配对状态。
此时，键盘的第一个指示灯将闪烁，指示灯颜色为蓝色。
3)打开设备的蓝牙功能，搜索"ML-981"并连接。

使用有线模式连接设备
1)将模式开关切换到"USB"位置

2)用包装中的Type-C数据线连接键盘和设备。

③ 系统开关


④Type-C端口
当第四个指示灯变红时，需要用Type-C充电线充电。
通常需要6个小时左右充满电。

⑤ 右旋钮
旋转左旋钮调节灯光亮度

⑥可通过拨动拨杆来切换背光模式



指示灯说明




① 模式指示灯
有线模式:第一个指示灯为红色
将开关推到USB位置，打开机使用Type-C数据线与电脑连接，为有线模式。
蓝牙模式:第一个指示灯为蓝色
将开关推到BT位置，按住FN和Q/W/E键并保持3秒，此时第一个指示灯保持蓝色闪烁，然后打开设备中的蓝牙开关以完成配对。

② WIN锁指示灯
按FN+WIN键禁windows锁定键的开关。
当Win功能打开时，灯蓝蓝色的同时win键没有任何功能。
当锁定键关闭和Win键恢复功能时，指示灯熄灭。

③ 大写锁定指示灯(A/a)
按CapsLK键是大写锁定开关。当大写锁定功能开启时，第三个指示灯为蓝色，再次按下指示灯熄灭，大写字母功能关闭。

④ 充电指示灯
当电压低于3.4V且第四个指示灯为红色并闪烁时，表示键盘需要充电;充电时蓝色指示灯固定。
充满电后灯会灭。



FN组合键说明

Window/Android

FN+F1	我的电脑
FN+F2	搜索
FN+F3	计算器
FN+F4	多媒体
FN+F5	上一首
FN+F6	下一首
FN+F7	暂停/放
FN+F8	停止
FN+F9	静音模式
FN+F10	音量减低
FN+F11	音量调高
FN+F12	键盘锁定
FN+Win	Win锁

Mac/ios

F1	屏幕亮度
F2	屏幕亮度+
F3	调用所有程序
F4	启动界面
F5	键盘亮度
F6	键盘亮度+
F7	最后一首歌
F8	放/暂停
F9	下一首歌
F10	无声
F11	音量调低
F12	音量调高
Prtsc	屏幕截图
Pause	启动Siri

背光组合键说明

FN+↑ FN+↓	调整亮度
FN+← FN+→	调闪烁速度
FN+Del	背光开/关
FN+Home	灯效模式切换
FN+Esc	按3秒恢复原设计

多设备蓝牙模式

① 三个设备的蓝牙已配对并连接到相应的FN+Q/FN+W/FN+E
② 如何在3台设备之间切换:按FN+Q/W/E=设备1或设备2或设备3

睡眠模式

在蓝牙模式下，5分钟内不使用它将进入睡眠模式,按任意键即可恢复。

轴体参数

青轴	红轴
耐久寿命:50万次以上	耐久寿命:50万次以上
触发压力:45±50gf	触发压力:45±50gf
触发行程:2.2±0.5mm	触发行程:2.2±0.5mm
操作类型:段落感(青轴)	操作类型:线性(红轴)
总行程:4.0+0/-0.6mm	总行程:4.0+0/-0.5mm

规格参数

- 按键数量:83键
- 多媒体按键数量:12键
- 材料:ABS和金属
- 电池:2000毫安
- 充电时间:约6小时
- 接口:Type-C
- 模式:蓝牙和有线
- 蓝牙版本:5.0

- 蓝牙设备名称:ML-981
- 开关寿命:>50万
- 键盘功能:所有按键防冲突
- 回报率:125 Hz
- 电缆长度:1.6米
- 键盘尺寸:32.5x 17 x 4cm
- 净重:约720g

装箱清单

- OU981机械键盘*1
- 旋轴器*1
- 备用轴体*2
- Type-C数据线*1
- 使用说明书*1

售后支持　蓝牙连接指南　官网

品牌:OUSEI
品牌方:立千科技有限公司
客户服务:fangjufang@li-qian.com
官网:www. ouseitech.com
电话:0755-82762100
产品执行标准:GB/T 14081-2010
版权所有® 立千科技有限公司